



ITEM NO.	PART NO.	DESCRIPTION	QTY REQ'D
1	23434	Upper Housing-BeautéMaster.....	1
	23454	Upper Housing-SpeedMaster.....	1
	23459	Upper Housing-Ultra.....	1
2			
3			
4	23488	Field Assy & Cord.....	1
5			
6	23473	Foam Pad.....	1
7	23432	Pivot Spring.....	2
8	23468	Pivot Arm Assy.....	1
	23542	Pivot Arm Assy (PowerMaster only).....	1

ITEM NO.	PART NO.	DESCRIPTION	QTY REQ'D
9	23469	Lower Housing Assy (UL).....	1
10	23493	Adjustment Lever.....	1
11			
12	18124	Adjustment Lever Screw.....	1
13			
14	23499	Tension Spring.....	1
15	64873	Blade Guide.....	1
16	18127	Blade Screws.....	2
17	23472	Housing Screws.....	2
18	23489	Hanger Loop.....	1
19	23474	Cord Retaining Bracket.....	1
20	18119	Retaining Bracket Screws.....	2

IMPORTANT INFORMATION

When ordering repair parts, include part number, part name and model of clipper/trimmer. For best performance, clipper/trimmer should be CLEANED and OILED with Andis Clipper Oil before and after use. If repair is necessary, return to any Andis Authorized Repair Service Station, or to Andis Company, 1800 Renaissance Blvd., Sturtevant, Wisconsin 53177 U.S.A. Carefully pack and mail either insured Parcel Post, or U.P.S., attach a letter to outside of package explaining difficulty.