



ITEM NO.	PART NO.	DESCRIPTION	QTY REQ'D
1	80008	Heating Element	1
2	80009	AC Motor and Fan	1
3	80013	Motor Screw	2
4	80014	Rear Housing	1
5	80019	Air Intake Grill.	1
6	80049	Housing Screw	2
7	80052	Cord with ALCI.	1
8	80035	Cord Strap Screw	2
9	80034	Metal Cord Strap	1
10	80033	Fiber Cord Strap	1

ITEM NO.	PART NO.	DESCRIPTION	QTY REQ'D
11	80023	Switch - Off/Air Speed - Black	1
12	80025	Switch - Heat Control - Red	1
13	80056	Switch - Cool Shot - Momentary	1
14	80057	Switch Actuator.	1
15	80058	Front Housing.	1
16	80069	Hanger	1
17	80071	Concentrator Attachment-Plastic	1
	80081	Concentrator Attachment-Aluminum	1
18	80072	Outlet Grill	1
19	80073	Mica Liner.	1

IMPORTANT INFORMATION

When ordering repair parts, include part number, part name and model of hair dryer.

If repair is necessary, return to any Andis Authorized Repair Service Station, or to Andis Company, 1800 Renaissance Blvd., P.O. Box 085005, Racine, Wisconsin 53408-5005 U.S.A. Carefully pack and mail either insured Parcel Post, or U.P.S., attach a letter to outside of package explaining difficulty.