andis®

MODEL PM–2 CLIPPER
120 VOLT



ITEM NO.	PART NO.	DESCRIPTION	QTY. REQ'D
1	23463	Upper Housing	na
2	23433	Switch Actuator	1
3	23488	Field Assembly & Cord	1
4	23479	Motor Screws	na
5	23473	Foam Pad	1
6	23432	Pivot Spring	1
7	23468	Pivot Arm Assy.	1
8	23471	Lower Housing Assy.	1
9	23493	Adjustment Lever	1
10	23494	Blade Bracket	na
11	18124	Adjustment Lever Screw	1
12	23478	Tension Spring Screws	na
13	23499	Tension Spring	1
14	64873	Blade Guide	1
15	18127	Blade Screws	1
16	23472	Housing Screws	2
17	23489	Hanger Loop	2
18	23474	Cord Retaining Bracket	1
19	18119	Retaining Bracket Screws	1

ITEM NO.	PART NO.	DESCRIPTION	QTY. REQ'D

IMPORTANT INFORMATION

When ordering repair parts, include part number, part name and model of trimmer. For best performance, trimmer blades should be CLEANED and OILED with Andis Clipper Oil before and after use, If repair is necessary, return to any Andis Authorized Repair Service Station, or to Andis Company, 1800 Renaissance Blvd., Sturtevant, Wisconsin, 53177 U.S.A.. Pack carefully, mail either Insured Parcel Post, or U.P.S. , attach a letter to outside of package explaining difficulty.